

HOW TO ADJUST YOUR CLOUD CHAIR

**AFRDI
CERTIFIED**
FOR USERS UP TO
135KG

HANDLE
BENEATH SEAT
AT RIGHT

SEAT SLIDE

Lift weight off seat and slide seat forward or backward while holding the handle out.

FRONT
RIGHT HANDLE

SEAT/BACK TILT TENSION

Wind forward to increase tension.
Wind backward to lighten tension.

FRONT
RIGHT LEVER

GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift.
Take your weight off the seat and lift lever to raise the gaslift.

ADJUSTABLE LUMBAR SUPPORT

Slide lumbar support up and down as required or slide out to remove completely.

MULTI-ADJUSTABLE ARMRESTS

Use button at front to adjust height.
Armrest pad position can be adjusted by sliding back or forward.

FRONT
LEFT
LEVER

SEAT/BACK SYNCHRO TILT

Turn forward to release seat/back synchro tilt.
Turn backward to lock in desired position.

MAX TILT RANGE

Keep switch at front of mechanism at top point for maximum tilt range.



EDEN

CLOUD ERGO



10YR	WARRANTY: FOR NORMAL OFFICE USE
140KG	RECOMMENDED MAXIMUM USER WEIGHT
135KG	CERTIFIED *
AFRDI LEVEL 6	AUSTRALIAN / NZ STANDARD FOR COMPUTER CHAIRS
GREENGUARD GOLD	GREENGUARD GOLD CERTIFIED*

*AFRDI 142 cert for 135kg users

*Product Certified for Low Chemical Emissions: UL.com/GG UL2818

SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust the lumbar support height so that it fits into the lumbar contour of your back.

Adjust the tilt tension so that when the synchro tilt is released the chair supports your weight in an upright seated position but allows you to lean back easily if you choose.

Sit close to your workstation.

Your feet should be flat on the floor or on a footrest.

Keyboarding and mouse operation should be achieved comfortably without stretching.

WARRANTY

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure on Cloud chairs. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

CHAIR CARE

The **mechanical parts** of your Cloud chair require little or no maintenance.

The **castors** should be kept clear of threads or other objects that would inhibit their movement.

The **gaslift** contains pressurised gas and should not be tampered with in any way.

The **foam and standard fabric** used in the upholstery of Cloud chairs comply with standard AS/NZS 4088.1:1996.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.

This chair is covered in:

- Polyester fabric
- Other