HOW TO ADJUST YOUR CONTROL CHAIR



MULTI-SHIFT USE

REAR RIGHT LEVER

SEAT ANGLE

Turn forward for a forward tilt seat position.

Turn back for a level seat position.

ROUND RIGHT HANDLE

SEAT/ BACK TILT TENSION

Turn backward to increase tension.

Turn forward to lighten tension.

FRONT RIGHT LEVER

GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift.

Take your weight off the seat and lift lever to raise the gaslift.

ADJUSTABLE HEADREST

Slide up to adjust height. Twist in or out to adjust angle.

HEIGHT-ADJUSTABLE ARMRESTS

Use button on side of armrest to adjust height.

ROUND LEFT HANDLE

SEAT/BACK SYNCHRO TILT

Turn forward to release seat/back synchro tilt.

> Turn backward to lock in desired position.

FRONT LEFT LEVER

SEAT SLIDE

Take your weight off the seat, lift lever, and slide seat forward or backward to adjust position.

EDEN

CONTROL



10YR WARRANTY RECOMMENDED **160**KG MAXIMUM SUITED FOR **24HR** 24-HOLIPLISE AS/NZS 4438: AUSTRALIAN / NZ LEVEL6 COMPUTER CHAIRS AFRDI CERTIFIED AFRDI 142 **160**KG CERTIFIED FOR 160KG AFRDI RATED LOAD MULTI-SHIFT

SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust the tilt tension so that when the synchro tilt is released the chair supports your weight in an upright seated position but allows you to lean back easily if you choose.

Sit close to your workstation.

Your feet should be flat on the floor or on a footrest

Keyboarding and mouse operation should be achieved comfortably without stretching.

WARRANTY

Control is warrantied for 10 years including in multi-shift and 24-hour situations.

The recommended maximum user weight is 160kg.

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

CHAIR CARE

The mechanical parts of your Control chair require little or no maintenance

The castors should be kept clear of threads or other objects that would inhibit their movement.

The gaslift contains pressurised gas and should not be tampered with in any way.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.