HOW TO ADJUST YOUR CREW CHAIR

RATCHET BACK LIFT BACKREST HEIGHT

Click backrest upwards with both hands till it reaches the desired height.

(When it reaches the top of the 8 ratchet positions it will return to the bottom of the range.)

REAR RIGHT LEVER BACKREST ANGLE

Lift lever to allow the backrest to tilt.

Lower the lever to fix the angle.

FRONT RIGHT LEVER GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift.

Take your weight off the seat and lift lever to raise the gaslift.

BENEATH SEAT FRONT LEVER SEAT SLIDE

Lift weight off seat and slide seat forward or backward with the lever lifted.

REAR LEFT LEVER SEAT ANGLE

Lift lever to allow the seat to tilt.

Lower the lever to fix the seat angle.

EDEN

CREW







GOLD CERTIFIED*



100% Wood from wellmanaged forests FSC^e C182102

*AFRDLL evel 6: Crew standard model *Product Certified for Low Chemical Emissions: UL.com/GG UL2818

SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust your backrest height so that the lumbar support fits into the lumbar contour of vour back.

Adjust your backrest angle, seat angle, and seat height to a position that allows you to sit close to your workstation.

Your feet should be flat on the floor or on a footrest. There should be no pressure under your thighs.

Keyboarding and mouse operation should be achieved comfortably without stretching.

WARRANTY

Crew is warrantied for 10 years in normal commercial-use situations.

The recommended maximum user weight is 160kg.

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

CHAIR CARE

The mechanical parts of your Crew chair require little or no maintenance.

The **castors** should be kept clear of threads or other objects that would inhibit their movement.

The gaslift contains pressurised gas and should not be tampered with in any way.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.